INSTALLATION INSTRUCTIONS **MODEL 15423 WATER FILTER**

For Haisey Taylor Models S, SW, WM, ŚCWT, BFC, & HBW

(Fittings will accommodate 3/8" & 1/4" OD copper tubing only.)

CAUTION -

Do not use filter in locations subjected to sub-freezing temperatures or where water is microbiologically unsafe or of unknown quality without adequate disinfection before or after filter

Instructions for Filter Installation

1. Turn off water supply; dispense water to relieve pressure.

2. Remove Y-strainer from the inlet tubing, see fig A for operation of fittings.

3. Install filter with water flow in direction indicated.

4. Outlet of filter must be 2 inches higher than inlet to prevent air from being trapped inside.

5. Turn water supply on, check fittings for leaks.

6. Dispense approximately 1 gallon of water to flush any particulate from the filter.





Figure A

Quick Connect Fitting Hookup

1. For correct "leak-free" hookup, tube surface must be smooth with no scratched or dents.

2. Damaged tubing, old compressions fitting "ferrules", ect. must be removed.

3. Cut end of tube must be "de-burred". Burrs on the ends of the tube end will cut the "O-ring" seal.



| Item No. | Part No. | Description | Qty. |
|----------|----------|---------------------------|------|
| 1 | 55935C | Filter - Assy | 1 |
| 2 | 62181C | Tube-Cu 1/4 X 5.00 | 1 |
| 3 | 70745C | Union-3/8 X 1/4 | 1 |
| 4 | 70828C | Conn-Male 1/40D X 1/4NPTF | 1 |
| 5 | 75525C | Connector-Male (NPTF) | 1 |
| 6 | 96901C | Label - Filter | 1 |

Notes:

- 1. Item No. 1 includes Items 4, 5, and 6.
- 2. Assembled filter is setup for 3/8" OD water in and 1/4" OD water out. For 3/8" OD water out add adapter fitting and tube, items 2 and 3.

OAK BROOK, IL 60521 (708)574-3500

PRINTED IN U.S.A.