

Parts List for Water Cooler Models: NWCA-5HF & NWCA-8HF

ITEM	PART NUMBER	DESCRIPTION
1	AA00005-SP	Tecumseh Compressor -8HF
	AA00005-T1	Tecumseh Overload -8HF
	AA00005-T2	Tecumseh Relay -8HF
	AA00007-SP	Tecumseh Compressor -5HF
	AA00007-T1	Tecumseh Overload -5HF
	AA00007-T2	Tecumseh Relay -5HF
	AA00027-SP	Compressor 115V (uses Spade Connections)
	C026403-10	Relay MRP26All-69 (uses Spade Connections)
	C026411-06	Overload 9660-042-166 (uses Spade Connections)
2	C026398	Condenser
3	B153475	Fan Motor (eyelet)
	D036186-02	Fan Motor (uses Spade Connections)
4	C026400-01	Fan Blade
5	C026081	Wiring Harness (eyelet)
	C026392-01	Wiring Harness (uses Spade Connections)
	C026382-04	16" Wire Assembly (uses Spade Connections)
6	AA00004	Drier
	C026498-705	Capillary Tube
	C026376-03	Cold Thermostat (uses Spade Connections)
7	A016241	Cold Thermostat (eyelet)
8	C026263	Drain
9	A015671	Drain Washer
10	A016762	Drain Screw
11	C026293-SP	Cobra Spout (metal)
	11432	Safety-Gard™ Spout Assy (Optional)
12	A021220	Spring Washer
13	A021112	Binder Nut
14	10947-003-SP	Water Control Assembly
15	B153468-01	Cartridge
16	A020957	Retainer Nut
17	A020938-01	"Y" Strainer
18	C026148-SP	Evaporator
19	D035878	Stainless Steel Top
20	A016135	Stainless Steel Screws
21	A016519	Hole Cover
22	B154379	Hanger Bracket
23	D035764-31	Left Side Panel - Stainless Steel
	D035764-19	Left Side Panel - Pewter
24	D035765-31	Right Side Panel - Stainless Steel
	D035765-19	Right Side Panel - Pewter
25	C026326-31	Front Panel - Stainless Steel
	C026326-19	Front Panel - Pewter
26	D036033	Bottom Panel
27	10221-SP	Apron Assembly - Stainless Steel with Sensor
28	B154299	Cover Plate
29	B154298	Mounting Plate
30	A020144	Sensor
31	A020598	Solenoid Valve
32	A019182	Junction Box
33	A019189	Activator Bracket

NOTE: Contact service department for information on compressors not shown on this page. This sheet cancels all previous lists for this model.